

Rotalock Straight Connector

Part No.	Description
RL-SC-1401	Rotalock Straight Connector - 1/4 ID x 1 R/L Nut
RL-SC-3834	Rotalock Straight Connector - 3/8 ID x 3/4 R/L Nut
RL-SC-1201	Rotalock straight connector - 1/2 ID x 1 R/L Nut
RL-SC-5801	Rotalock Straight Connector - 5/8 ID x 1 R/L Nut
RL-SC-7801	Rotalock Straight Connector - 7/8 ID x 1 R/L Nut
RL-SC-7814	Rotalock Straight Connector - 7/8 ID x 1-1/4 R/L Nut
RL-SC-1814	Rotalock Straight Connector - 1-1/8 ID x 1-1/4 R/L Nut
RL-SC-1834	Rotalock Straight Connector - 1-1/8 ID x 1-3/4 R/L Nut
RL-SC-1384	Rotalock Straight Connector - 1 3/8 ID x 1 3/4 R/L Nut



Rotalock Elbow Connector

Part No.	Description
RL-EC-3834	Rotalock Elbow Connector - 3/8 ID x 3/4 R/L Nut
RL-EC-1201	Rotalock Elbow Connector - 1/2 ID x 1 R/L Nut
RL-EC-5801	Rotalock Elbow Connector - 5/8 ID x 1 R/L Nut
RL-EC-5814	Rotalock Elbow Connector - 5/8 ID x 1 1/4 R/L nut
RL-EC-3401	Rotalock Elbow Connector - 3/4D x 1 R/L Nut
RL-EC-7801	Rotalock Elbow Connector - 7/8D x 1 R/L Nut
RL-EC-7814	Rotalock Elbow Connector - 7/8 ID x 1 1/4 R/L Nut
RL-EC-1814	Rotalock Elbow Connector - 1-1/8 ID x 1-1/4 R/L Nut
RL-EC-1834	Rotalock Elbow Connector - 1-1/8 ID x 1-3/4 R/L Nut
RL-EC-5824	Rotalock Elbow connector - 1 5/8 ID x 2 1/4 R/L nut



Rotalock Valve Flare

Part No.	Description
RL-MF-1434	Rotalock Valve 1/4 Flare x 3/4 R/L
RL-MF-3834-NA	Rotalock Valve 3/8 Flare x 3/4 R/L Nut- No Access
RL-MF-3834	Rotalock Valve 3/8 Flare x 3/4 R/L Nut
RL-MF-1201	Rotalock Valve 1/2 Flare x 1 R/L Nut

